




**Anleitung für die Modelle
345205 + 345206 + 345220 + 345221**

Einstellen der Zeit:




1.1




1.2

Beachten Sie: Drücker sollten nicht in der Zeit von 21-3 Uhr betätigt werden, da sonst Schäden am Uhrwerk entstehen können. Einstellungen können nicht durch Drehen gegen den Uhrzeigersinn rückgängig gemacht werden. Dieses Vorgehen sorgt für Beschädigung des Kalendermechanismus.


Einstellen des Kalenders:




Einstellen des Monats:



Einstellen der Woche:



Aufziehen des Uhrwerks:



Selva
Exklusiv Edition



Selva Technik Deutschland
Christian-Messner-Straße 29
78647 Trossingen
service@selva.de
Support: 07425 930300

Selva Technik Suisse
Postfach/Case Postale 333
1723 Marly 1 / Schweiz
service@selva.de
Support: 026-439 92 40

Selva Technik Austria
Hiefbauerstrasse 3
8790 Eisenerz / Österreich
service@selvatime.at
Support: 03848 / 2213

**Specification 345205 + 345206
+ 345220 + 345221**

Adjust the time:




1.1


1.2

Important notice : 1. Push-buttons must not be used during the period of 9pm (evening) till 3am (morning), as otherwise the movt will be damaged.
2. Time adjusting must not be reversed anti-clockwise to adjust the calendar. This will damage the calendar jumping mechanism.


Adjust the Calendar




Adjust the Month



Adjust the week



Tighten up mainspring



Selva

Exklusiv Edition

Selva Technik Deutschland
Christian-Messner-Straße 29
78647 Trossingen
service@selva.de
Support: 07425 930300

Selva Technik Suisse
Postfach/Case Postale 333
1723 Marly 1 / Schweiz
service@selva.de
Support: 026-439 92 40

Selva Technik Austria
Hieflauerstrasse 3
8790 Eisenerz / Österreich
service@selvatime.at
Support: 03848 / 2213